BE ALERT FOR THE

BITTPES OF WASTE

- D Defects (errors that cause rework, reclassification, or scrap)
- O Overproduction (producing a higher quantity than what's needed)
- W Waiting (people, parts, and equipment not being fully employed)
- N Non-standard and Overprocessing (doing more than what's needed on a unit)
- ${f T}$ Transportation (moving people, parts, and equipment unnecessary distances)
- I Injuries (people getting hurt, equipment and parts damage)
- M Motion (excessive movement within a work cell)
- E Excess Inventory (having more parts/supplies than what can be obtained or consumed within a reasonable time)

What You Can Do:

IDENTIFY it.
PREVENT it.
REDUCE it.
ELIMINATE it.



Career tech

Resource Center for
RCCTA Resource Center for
CareerTech Advancement
https://www.okcareertech.org/educators/resource-center