



TASK SEATING



Comfort Rx

(Without headrest - shown)

This chair offers a unique seating concept designed to help eliminate back, hip and tailbone discomfort that often results from sitting for extended periods of time. With its unique design, the Comfort Rx is able to conform to individual user needs, providing bone and muscle support throughout the day. Features include: laminated back foam densities, adjustable back height/angle, memory foam seat & back overlay, mechanical adjustable lumbar support, soft urethane arm pad for ergonomic comfort, vertical/horizontal/forward/rearward arm adjustment, scalloped seat center, a horseshoe seat gel that cradles and comforts the upper thigh, a waterfall seat front to relieve back stress and an integral seat depth slider.

DIMENSIONS

Back: 25" H

Seat: 20 1/2" W, 19" D

Seat Ht Range: 17 3/4" - 21 3/4"

FABRIC COLOR: EBONY

FRAME COLOR: BLACK

Item No. 122RX142 (*Without headrest - shown*)

\$643.00

Item No. 122RX141 (*With headrest*)

\$688.00

FEATURES AND OPERATIONAL INSTRUCTIONS

Back Height Adjustment

Lift to highest position and quickly drop back, allow to lowest position. Slowly lift back until it clicks into desired height.

Arm Height Adjustment

Squeeze button under arm pad to raise or lower to desired height.

Lumbar Support

Turn handwheel to adjust as desired.

Gas Lift Adjustment

Lift lever to activate gas cylinder and use body weight to adjust height.

Arm Pad Adjustment

Press button under front of armpad to move armpad forward or rearward.

Arm Width Adjustment

Squeeze lever under arm to adjust to desired width.

Seat Tilt Lock Adjustment

Lift lever up and tilt seat to desired position. Lock into position by pushing lever back down.

Seat Slider

Lift lever up and slide seat forward or backward to desired position. Release to lock.

3 Position At Rest Angle Adjustment

Lean back slightly and rotate the knob to the desired at rest angle position. The seat and back will return to the selected angle when the chair is returned to the forward position.

Seat Tilt Tension Adjustment

Turn knob clockwise to increase tilt tension.
Turn counter clockwise to decrease.



OKLAHOMA
Correctional
Industries