

STATE OF OKLAHOMA BOARD OF TESTS FOR ALCOHOL AND DRUG INFLUENCE

Dr. Jarrad Wagner, Ph.D. F-ABFT Chairman

Post Office Box 36307 Oklahoma City, Oklahoma 73136-2307 Phone: (405) 425-2460 Fax: (405) 425-2490 www.bot.ok.gov

Joshua Smith Director

ATTESTATION

I, the undersigned <u>Joshua Smith</u> (Director/Records Custodian), attest under oath pursuant to 12 O.S. §2902 (11)(a) this record was made, at or near the time of the occurrence of the matters set forth by or from information transmitted by a person having knowledge of those matters; was kept in the course of the regularly conducted business activity of the Board; and was made pursuant to the regularly conducted activity. The duplicate record provided is listed below:

1) The attached "Service Overview" is a true and accurate copy of maintenance performed on the Intoxilyzer 8000, serial number 80-003291 , in compliance with the agency's Maintenance Policy and Procedures.

This packet consists of 16 pages.

Signed _____

Name of Position: Director/Records Custodian

Date of Attestation: 01/11/2021

Service Overview



3600 N. Martin Luther King Bldg #9 Oklahoma City, OK 73111 405-425-2460

BENCH CHECK DATE: 01-11-2021

SERIAL: 80-003291

DOCUMENTATION WITHIN SERVICE PACKET:

- BOT Certificate of Calibration and Operation
- CMI Certificate of Calibration 12-08-2020
- Bench Check
- Bench Check Technician's Report
- BOT Dry Gas Certificate of Analysis
- CMI Service Evaluation Form
- CMI Work Order
- Mock Subject Test
- BOT Certificates of Analysis on Certified Solutions (4)



STATE OF OKLAHOMA BOARD OF TESTS FOR ALCOHOL AND DRUG INFLUENCE

Administrative Office at:
Board of Tests for Alcohol and Drug Influence
Post Office Box 36307
Oklahoma City, Oklahoma 73136-2307

Certificate of Calibration and Operation

This is to certify that the calibration of INTOXILYZER 8000, serial number 80-003291, manufactured by CMI Inc., a subsidiary of MPD, Inc. of Owensboro, Kentucky, was tested and found to be in compliance with National Highway Traffic Safety Administration Standard for Devices to Measure Breath Alcohol (F.R., No. 179 48705-48710 Sept. 17, 1993) and with International Recommendation OIML R 126 Edition 1998 (E). Calibration solutions are traceable to NIST standard material 1828.

In addition the operational procedures and functions of this Intoxilyzer have also been tested and found to be in compliance with the Oklahoma Board of Tests for Alcohol and Drug Influence - Rules and Regulations OAC Title 40: 25-1-2 and 30-1-3 and is hereby certified for use as an evidential breath testing device within this state.

DATE
07-21-08
08-22-08
09-04-09
07-13-11
10-13-11
07-24-13
07-29-13
05-18-15
03-14-17
05-24-17
11-28-18
12-08-20
01-11-21



Presentation of this form certifies that the Intoxilyzer, SN: 80-003291, functioned properly at the time of the breath test and hereby certifies the breath test result as valid.

Date:

Re: Request for Log of Test on Intoxilyzer 8000

Name:

Dear Sir:

The Log of Test information from a breath test conducted on a Intoxilyzer 8000 is printed in Section 2 the Affidavit and is no longer retained as a separate form as with the Intoxilyzer 5000. The 8000 uses a nitrogen/ethanol dry gas for the external control test. The dry gas cylinder has the capacity to perform approximately 325 tests and does not require maintenance until its expiration date or can no longer provide the required pressure to perform a control test. The cylinder has an expiration date of two years from date filled at the manufacturer and is programmed in the 8000 upon installation, both dates are printed in Section 2 of the Affidavit. The Intoxilyzer is programmed to disable itself when the date of expiration is reached or the pressure monitor indicates 25 lbs psi.

Due to the reliability and stability of dry gas, maintenance on the 8000 is not required every 30 days or 25 tests, therefore maintenance is no longer performed by officers in the field. The Board of Tests for Alcohol and Drug Influence certifies each Intoxilyzer 8000 for field use by performing a bench check. The bench check is designed to check the operation and procedures programmed in the 8000 to ensure it is functioning properly for use in Oklahoma. A bench check is performed every time a new dry gas cylinder is installed or the instrument has returned from the manufacturer for repair. instrument passes the bench check, all that is required to set it up for field use is to plug it in and turn it on and does not require a permit to set up. The Board of Tests has the ability to monitor each instrument once it is set up in the field.

Each Intoxilyzer has a database of valid permit numbers that it checks prior to allowing a breath test to be performed. The database is updated on a regular basis, if a permit number is invalid that officer will not be able to conduct a breath test on the 8000. If the 8000 prints an affidavit the breath test operator listed in Section 2 had a valid permit at the time of the test and the breath test is valid.

If you have any further questions please feel free to call me.

Sincerely,

J. Robert Blakeburn (OBA11059) State Director of Tests for Alcohol and Drug Influence

phet Blakeline

Certificate of Calibration

This is to certify the calibration of INTOXIVZET ® serial number 80-003291, manufactured by CMI Inc., a subsidiary of MPD, Inc. of Owensboro, Kentucky, was tested and found to conform to the National Highway Traffic Safety Administration (NHTSA) Standard for Devices to Measure Breath Alcohol (Federal Register, Vol.58, No.179, pp 48705-48710, Sept. 17, 1993) for accuracy and precision. Reference materials are traceable through the National Institute of Standards and Technology (NIST) to the International System of Units (SI).

Date <u>Mec 08, 2020</u> Signed <u>Alice Jo</u>
Technician
Technician

316 East 9th Street Owensboro, KY 42303

Part No. 650517 Rev.A

STATE OF OKLAHOMA - BOARD OF TESTS FOR ALCOHOL AND DRUG INFLUENCE

	WI INTOXILYZ	ER BENCH C	HECK PROC	EDURE RE	PORT		
NCH CHECK DATE 01/11/2021	BEGAN 3	INSTRUMENT LOCATION 80-003291					
TRUMENT TYPE Intoxilyzer	100.7 7 37 4	UMENT MODEL - 8000		80-00	NT SERIAL NUMBER		
ncoxilyzei	1-	- 78-14 WED -	ESULTS	80-00	3291		
Diagnosti PASS							
Mouth Alcoho	ol Test						
PASS							
RFI Tes	t						
PASS		Di	plicate Breath	Sampling Re	esults		
Abort Te PASS		Value	Test 1	Test 2	Control Test		
Improper Samp PASS	TO THE PERSON NAMED IN COLUMN TWO IN COLUMN	.02	0.019	0.018	0.020		
Interferent Dete	ect Test	.04	0.038	0.037	0.039		
PASS		.10	0.100	0.098	0.100		
No Sample Giv	en Test		1 2 11 20 20 20 2	3 2 3 3 3 3			
PASS		.20	0.201	0.198	0.199		
Insufficient Sam PASS Air Blank Contami			PA	ASS			
PASS							
Range Exceede							
		CERTIFYING	TECHNICIAN	A-11-11-1			
I swear under penalty the Intoxliyzer Bench		in regards to the	e above listed	of Oklahoma.			
NATURE				DATE			
Marine	Popo	23026		1/	11/2021		
APE, CHRISTO	PHER			PERMIT #	0023020		

End Time: 09:30

3600 N. Martin Luther King Bldg #9 Oklahoma City, OK 73111 405-425-2460

BENCH CHECK TECHNICIAN'S REPORT

Start Time: 08:35

Date: 01/11/2021

0000		Serial #	201
8000		80-003	291
GAS CANISTER		EVD D. I	
OT# 22620080A2-018		EXP Date 10/05/2	022
REFERENCE		10/03/2	022
KEFEKENCE	Simul	ator Model	
Guth 2100	Guth 2100	Guth 2100	Guth 2100
	-	Serial #	
DR2834	DR3700	DR2455	DR3470
.02	.04	ncentration .10	.20
.02	.04	LOT#	.20
20070	20060	20190	20160
	Manu	factured Date	1000000
02/13/2020	02/10/2020	04/06/2020	03/18/2020
4444444		iration Date	
02/13/2022	02/10/2022	04/06/2022	03/18/2022
		Commission Date	
1/4/2021	1/4/2021	1/4/2021	1/4/2021
1/4/2021 REASON FOR BEI POST REPAIR TROUBLESHOOT COMMENTS	NCH CHECK CYLINDER REF	PLACEMENT	1/4/2021
REASON FOR BEI POST REPAIR	NCH CHECK CYLINDER REF	PLACEMENT IE MAINTENANCE	1/4/2021
REASON FOR BEI POST REPAIR TROUBLESHOOT OMMENTS	NCH CHECK CYLINDER REF	PLACEMENT IE MAINTENANCE	1/4/2021
REASON FOR BEI POST REPAIR TROUBLESHOOT OMMENTS	NCH CHECK CYLINDER REF	PLACEMENT IE MAINTENANCE	1/4/2021
REASON FOR BEI POST REPAIR TROUBLESHOOT OMMENTS	NCH CHECK CYLINDER REFING ROUTIN	PLACEMENT IE MAINTENANCE	1/4/2021
REASON FOR BEI POST REPAIR TROUBLESHOOT OMMENTS Correction factor was	NCH CHECK CYLINDER REFING ROUTIN reading high, CMI r	PLACEMENT IE MAINTENANCE	1/4/2021

q/210L

0.000

0.079

0.000

0.079

0.000

0.079

0.000

0.079

0.000

0.079

0.000

0.078

0.000

0.079

0.000

0.079

0.000

0.079

0.000

0.079

0.000

0.0789

0.0003

0.4007

SN 80-004923

11:26

Time

11:26

11:27

11:27

11:27

11:28

11:28

11:29

11:29

11:30

11:30

11:30

11:31

11:31

11:32

11:32

11:32

11:33

11:33

11:34

11:34

11:35

RLPHR INSTRUMENT 2

Model 8000

09/22/2020

Test

Air Blank

Cal Check

Air Blank

Std Dev

Cal Check Stats Average

Rel Std Deu(%)

Intoxilyzer - Alcohol Analyzer

Certificate of	of Analysis – Dry Gas	
9/22/2020	0.080	TY AP
Date of Analysis	Labelled target value (g/210L)	
018	0.079	
Cylinder #	Average test result	
Christophes A	se colles fil 23	220
BOT Technician Name and Signatur		_specialty gases

In accordance with BOT Policy and Procedure Statement BRT-2.3.0, Maintenance, the above referenced dry gas cylinder is suitable for use as an external refer 217-245-2183 • Fax: 217-243-7634 • www.ilmoproducts.com

Certificate of Analysis

Certificate ID:

13253

Part #:

BAC105L080T

Cylinder Size:

105L

Lot Number:

22620080A2

Expiration:

10/5/2022-

XCV ()

0.080 BAC (For the calibration of instruments used to determine breath alcohol concentration)

Contents:

105 Liters @ 1000 psig 70°F (21°C)

Analytical

Reported

Accuracy

Analytical

Component:

Concentration:

(U, k=2):

Method:

Ethanol Nitrogen

208 ppm

Balance

+/-0.002 BAC(G/210L) NDIR

[5.2 ppm]

Distributed by:

CMI Inc. 316 East Ninth Street

Owensboro, KY 42303 Phone 866-835-0690 www.alcoholtest.com

*Traceable to:

Certified Reference Material - 262.4 µmol/mol

Ethanol in Nitrogen - Serial No. GN0015026 Lot No. 050319E11

Store in dry area, away from sources of heat, ignition and direct sunlight. Do not allow storage area to exceed 52 °C (125 °F).

Gas Lab Tech

Accreditation #61895

The calibration results within this certificate were obtained using equipment and standards capable of producing analytical results traceable to NIST, and apply only to the items contained on this certificate. ILMO Products Company makes no warranty or representation as to the suitability of the use of any information provided for any particular purpose. The information use is at the sole discretion and risk of the user. Liability shall be limited to established replacement cost of this material or service.

CMI INC. Service Evaluation Form

This form MUST be completed and enclosed with instrument to be serviced. Failure to complete and return this form may cause delays in service.

(Note: please :	ship items in the	ir original sh	ipping container	(s) or a similar protective box.)		
1. Contact informa	ation: Custon	ner Number	731362	(contact Customer Service)		
Name: Board	d of Tests		Phone: (405) 425 2460			
Fax: (405) 425	2490	Email: o	christopher.pape	@bot.ok.gov		
2. Bill to Address:	Board of Tests		Ship to Address:	Board of Tests		
	3600 N ML King,	Bldg 9		3600 N ML King, Bldg 9		
	OKC, OK 73111			OKC, OK 73111		
3. Serial Number:	80-003291	i	nstrument Model:	Intoxilyzer 500 / 8000		
Detailed Descrip Correction fac		h. Reading 1	.07 when other u	nits are reading 1.04.		
	Commission Assess		See also de la company	rs with instrument!*** Other \$		
			(1.50 the 1734 th			
Authorized By:			Ship	to:		
Chris Pape		Breath Testi	na Admin			
Name (Please Prin	nt)	Title	Provide the second seco	, Inc		
Chatter N	pe	10/6/2020	Attr	n: Service Dept.		
Signature		Date	316	East Ninth Street		
Ca	II: 405-425-2460 o	r email	Ow	ensboro, KY 42303		
	d estimate before		nade.			
				rs and may cause delays in servi		
				nates that are not repaired.		
	A A C. C. E. WELL 2 (12) 2 (2)	A STATE OF THE STATE OF	A SALES NO GOVERN	2 x 1 x 1 x 1 x 1 x 1 x 1 x 1 x 1 x 1 x		



316 E 9th Street / Owensboro KY 42303 / USA Phone: 866-835-0690 Fax: 270-685-6268

SERVICE WORK ORDER

405394

Bill To:

DATE: 10/13/2020

Oklahoma Board Of Tests Blvd Adcu Annex Bldg #9 3600 Martin Luther King Oklahoma City, OK 73136-3000

USA

Customer #: 731362 Phone: 405-425-2424 Fax: 405-425-2490 fax Ship To:

Oklahoma Board Of Tests Blvd Adcu Annex Bldg #9 3600 Martin Luther King Oklahoma City OK 73136-3000

USA

Phone: 405-425-2424

MODEL #: 002480OK

Serial Number: 80-003291

BILL CODE: Out of Warranty

EXTRA PARTS RCVD:

BT, SHELF

DESCRIPTION OF PROBLEM

CORRECTION FACTOR OF UNIT IS HIGH. READING 1.07 WHEN OTHER UNITS ARE READING 1.04.

WORK PERFORMED:

baro sensor/ erratic; O-ring/ cracked; RTC battery/ low; tygon tubing/ dirty; replaced parts listed; calibrated/ final tested;

PARTS USED

Seq. No.	Part	Description	Quantity
50	530030	TUBING,TYGON,.375IDx.562OD	2.00 IN
60	471201	O-RING,BUNA-N,-008,3/16inx5/16	1.00 EA
70	210119	SENSOR,SMD,PRESSURE	1.00 EA
80	650517	CERTIFICATE OF CALIBRATION	2.00 EA
90	441169	COVER DUST,5/8in x 1/2in	1.00 EA
100	470145	CAP,PLASTIC,.25IDx.50LG,RED	3.00 EA
110	470154	CAP,PLSTC,.406IDx.438562,RED	1.00 EA
120	470218	SEAL, TAMPER EVIDENT, SERVICE	1.00 EA
130	690040	BATTERY,3VOLT,LITHIUM,CR2032	1.00 EA

			TES						

Misc Code	Description	Hours
LABR	Service Repair Labor	
LCAL	Service - Calibration Adjust	0.50
LFT	Service - Cal / Final Test	1.00

Technician Name: Dewayne Varvel

SRV4053940001

OFFICER'S AFFIDAVIT AND NOTICE OF

11/16 REVOCATION/DISQUALIFICATION Section 1 ARREST DATE ARREST TIME 01/11/2021 0900 55 ARREST LOCATION BOT OKLAHOMA DATE OF BIRTH SUBJECT NAME RACE HEIGHT 08/09/1961 GAYLON LEVERNE M W 510 NORTH, 165 ADDRESS ZIP CODE 73133 3600 MARTIN LUTHER KING A OKLAHOMA CITY OK EXPIRATION DATE DRIVER LICENSE RESTRICTIONS ENDORSEMENTS CLASS T083454871 06/30/2019 M OK A VEHICLE MAKE PLACARD MOCK MOCK MOCK N OK N On the above date, time, and location, the above named person was arrested, and I had reasonable grounds to believe the person was driving or in actual physical control of a motor vehicle upon a public road, highway, street, turnpike, public parking lot, or other public place, or upon a private road, street, alley or lane which provides access to one or more single or multi-family dwelling within this state while under the influence of alcohol and/or other intoxicating substances as prohibited by law. (Describe driving behavior or circumstances): MOCK SUBJECT TEST Describe person's condition (odor, actions, etc.); POST REPAIR MAINTENANCE, INSTALL NEW CYLINDER THE PERSON WAS INFORMED OF THE IMPLIED CONSENT TEST REQUEST BREATH-ALCOHOL ANALYSIS RECORD, REPORT OF THE PERSON NAMED IN SECTION 1 ABOVE, and LOG OF TEST AND MAINTENANCE RECORD. Section 2 EQUIPMEN' SERIAL NUMBER SPECIALIST I-8000 OF TESTS 80-003291 BOARD STANDARD PERMIT NUMBER ARGET VALUE Dry 0.080 23020 DATE CYLINDER EXPIRES DATE CYLINDER INSTALLED 22620080A2 10/05/2022 ILMO 01/11/2021 OBSERVATION MOUTHPIECE A 15-minute (or greater) deprivation/observation 0905 01/11/2021 G period was observed prior to and continuing RESULT TABLE to the time of test administration. g/210L Time Test I administered said Breath-Alcohol Test in Air Blank 0.00 09:24 Subject Test 0.00 09:24 compliance with the applicable operating Breath Volume 1.480 LITERS procedure of the Board of Tests. 09:25 Air Blank 0.00 Wait 09:26 Air Blank 0.00 09:27 Subject Test 0.00 09:27 SIGNATURE OF OPERATOR 1.628 LITERS Breath Volume Air Blank 0.00 09:28 Cal Check 0.08 09:28 Test Result PAPE CHRISTOPHER Air Blank 0.00 09:28 BrAC g/210L 0000000484 0000023020 0.00 AGENCY BOARD OF TESTS EFFECTIVE THIRTY (30) DAYS FROM DATE SERVED. Notice of Revocation is given that your driver's license is revoked or denied for a period of one hundred eighty (180) days or more, if you refused or falled the state's test(s). In addition, your commercial driving privilege in this state will be disqualified if you refused or failed the state's test(s) Section 3 (operating a CMV or CDL holder) OR a test result of .04 or more white operating a commercial motor vehicle. You may appeal any Departmental action against your driver license as a result of this arrest by filing a petition in the District Court of the County in which you were arrested. Your petition must be filed within thirty (30) days of the date listed below. You may be eligible to participate in the Impaired Driver Accountability Program (IDAP) administered by the Department of Public Safety (DPS). Completion of IDAP may prevent a revocation as a result of this arrest from appearing on your driving record. Participation in IDAP may reduce the amount of fees you will be required to pay to the State. You must request IDAP within thirty (30) days of the date listed below. Mail the request for IDAP to the Department of Public Safety at P.O. Box 11415, Oklahoma City, OK 73136. SERVING OF NOTICE: I personally hand delivered a copy of the above containing the Notice of Revocation and the Notice of Department Impaired Driving Accountability Program to the person named in Section 1 above. Date served: 01/11/2021 Signature of officer: Badge #: In accordance with Title 12 O.S. Section 426, "I state under penalty of perjury under the laws of Oklahoma that the foregoing is true and correct." Section 4 Date: 01/11/2021 Place (location when signed): Signature of arresting officer NAME AGENCY PAPE CHRISTOPHER BOARD OF TESTS AGENCY ADDRESS ZIP CODE 0000000484 INTER-AGENCY 00000 4054252460 OTHER WITNESSES Section 5 NAME TITLE ADDRESS PHONE

NAME

2

ADDRESS

PHONE

TITLE

OFFICER'S AFFIDAVIT AND NOTICE OF REVOCATION/DISQUALIFICATION

12/16

01/11/2021		REST TIME		55	C	TY#	CITATIO	N#		Secti
RREST LOCATION					ITY		-	COUNT		812
BOT					In/re	P DIBTO	Terri		LAHC	and the same of the same of
NORTH, GAY	LON LEVERN	Œ			08	09/196	1 N		HEIGHT	WEIGHT 165
B600 MARTIN		110000		IOMA CIT	Y	, , , , , , , ,	STATE		73:	E
TO83454871			E	06/30/2	019		ASS A	RESTR	ICTIONS	ENDORSEME M
HICLE MAKE		MODEL		00,00,2	TA	G#		STATE	CMV	PLACARD
IOCK the above date, time, and loc	ation, the above named per	MOCE son was arrested, an	nd I had reasonable grounds	to believe the perso	n was driv	MOCK ing or in actual phy	sical control	OK of a motor ve	N shicle upor	N a public road,
hway, street, turnpike, public juence of alcohol and/or other escribe driving behavior or circ MOCK SUBJECT	Intoxicating substances as pounstances): TEST	rohibited by law.	te road, street, alley or lane	which provides acce	ss to one c	ir more single or m	oru-ramily ov	weiling within	this state v	mile under the
cribe person's condition (odo OST REPAIR M		INSTALL	NEW CYLINDE	R						
		THE PERSON	WAS INFORMED OF THE	IMPLIED CONSEN	T TEST RE	QUEST				
EATH-ALCOHOL ANALYSIS	RECORD, REPORT OF TH				_		o,			Section
UIPMENT				CIALIST		ama				
-8000 ANDARD		80	-003291 E		TES				-	
ry			0.080		3020					
NUFACTURER			LOT#	DAT	E CYLINDI	R INSTALLED		ATE CYLINDE		
LMO			2262008	30A2 0	1/11	/2021	7 1	10/05	/202	22
	L/11/2021	G MOUTHPIECE	A 15-minute (period was	or greater) dep observed prior			n		78 6	
Test	g/210L	Time	to the	time of test ac	lministr	ration.		132	***	128
Air Blank	0.00	09:24	I administere	d said Brea	th-Alo	cohol Test	in	3 *		1× × × 10
Subject Test	0.00	09:24	compliance	with the app	plicab	le operatin	g	0 *		*
Breath Volume	1.480 LITERS	00.05		re of the Bo		The state of the s	0	A **	7	(***)
ir Blank ait	0.00	09:25 09:26	procedu	it of the B	oaru o	i i ests.		1 m	1	**
ir Blank	0.00	09:27	1/11/11	26/1	> "	12000		10/	***	1
ubject Test	0.00	09:27	MATTE	1	d	20	_	1907		
Breath Volume	1.628 LITERS		SIGNATURE OF OPI	ERATOR					200	
ir Blank	0.00	09:28	NAME				- 1		4177762	
al Check ir Blank	0.08	09:28 09:28		STOPHER					Test Re	
A DECLER	0.00	03:26	BADGE #	PERI	MIT#	22020		В	rAC g/	
			00000048 AGENCY	Mary S. T.	0000	23020			0.0	00
			BOARD OF	TESTS						
	2 FD 214 B 1 7 F 2 FD 1/FD	CACHE SERVICE		to of Books to be ad-	Acres and the			ndred eighty		Section
ECTIVE THIRTY (30) DAY s or more, if you refused or eraling a CMV or CDL holde or result of this arrest by filing in may be eligible to partic ocation as a result of this uest IDAP within thirty (30	failed the state's test(s). er) OR a test result of .04 of a petition in the District of ipate in the Impaired Dri arrest from appearing on the date listed.	In addition, your co or more while opera Court of the County wer Accountability on your driving rec I below. Mail the r	mmercial driving privilege ating a commercial motor in which you were arreste Program (IDAP) admini cord. Participation in ID/ request for IDAP to the D	in this state will be vehicle. You may led. Your petition m istered by the Dep AP may reduce the Department of Pub	disqualification dispersion dispe	ed if you refused y Departmental a d within thirty (30 of Public Safety of fees you will y at P.O. Box 114	or failed the ction again) days of th (DPS). Co be require 15, Oklahe	e state's testi st your drive the date listed impletion of the d to pay to oma City, Ol	below. IDAP ma the State K 73136.	You must
s or more, if you refused or rating a CMV or CDL hold result of this arrest by filing may be eligible to partic cation as a result of this lest IDAP within thirty (30 RVING OF NOTICE: countability Program to	failed the state's test(s). ar) OR a test result of .04 of g a petition in the District of ipate in the Impaired Dri arrest from appearing of the date listed if personally hand delight person named in the	In addition, your co or more while opers Court of the County yer Accountability on your driving rec I below. Mail the r ivered a copy of n Section 1 about	mmercial driving privilege alting a commercial motor in which you were arreste Program (IDAP) admini lord. Participation in ID/ equest for IDAP to the D the above containing ve.	in this state will be vehicle. You may led. Your petition m istered by the Dep AP may reduce the Department of Pub	disqualification dispersion dispe	ed if you refused y Departmental a d within thirty (30 of Public Safety of fees you will y at P.O. Box 114	or falled the ction again) days of th (DPS). Co be require 115, Oklaho tice of De	e state's testi- st your drive- st your drive- se date listed smpletion of ed to pay to oma City, Of epartment	below. IDAP ma the State K 73136.	You must
s or more, if you refused or realing a CMV or CDL hold result of this arrest by filing may be eligible to partic totation as a result of this usest IDAP within thirty (30 RVING OF NOTICE: countability Program to e served:	failed the state's test(s). er) OR a test result of .04 g a petition in the District of ipate in the Impaired Dri arrest from appearing o ob days of the date listed it personally hand delign the person named in 1/2021 Sig	In addition, your co or more while oper: Court of the County ver Accountability on your driving red I below. Mall the r ivered a copy of n Section 1 about gnature of officer	mmercial driving privilege ating a commercial motor in which you were arreste y Program (IDAP) admini- ord. Participation in ID/ equest for IDAP to the D the above containing ye.	in this state will be vehicle. You may, dd. Your petition me Istered by the Dep AP may reduce the partment of Pub g the Notice of F	disqualificappeal an nust be file partment e amount olic Safety Revocati	ad if you refused y Departmental a d within thirty (30 of Public Safety of fees you will at P.O. Box 114 on and the No	or falled the ction again.) days of the (DPS). Co be require 15, Oklahottice of De	e state's testi st your drive e date listed mpletion of od to pay to oma City, Oi epartment	r license below. IDAP ma the State K 73136. Impaired	You must
s or more, if you refused or rating a CMV or CDL holds result of this arrest by filing may be eligible to particulation as a result of this sest IDAP within thirty (30 RVING OF NOTICE: countability Program to be served: 01/1.	failed the state's test(s). er) OR a test result of .04 g a petition in the District (ipate in the Impaired Dri arrest from appearing o)) days of the date listed b the person named in 1/2021 Sig 2 O.S. Section 426, "	In addition, your co or more while opera- Court of the County iver Accountability in your driving rec I below. Mail the re- ivered a copy of in Section 1 about gnature of officer	mmercial driving privilege ating a commercial motor in which you were arreste y Program (IDAP) admini- ord. Participation in ID/ equest for IDAP to the D the above containing ye.	in this state will be vehicle. You may a do. Your petition m istered by the Dep AP may reduce the partment of Pub g the Notice of F	disqualificappeal an ust be file partment e amount olic Safety Revocati	ad if you refused by Departmental a dividing the thing of Public Safety of fees you will at P.O. Box 114 on and the No a that the fore	or failed the ction again of the ction again of the ction again (DPS). Concept of the ction of t	e state's testi st your drive e date listed mpletion of od to pay to oma City, Oi epartment	r license below. IDAP ma the State K 73136. Impaired	You must
s or more, if you refused or realing a CMV or CDL hold result of this arrest by filing may be eligible to partic totation as a result of this test IDAP within thirty (30 RVING OF NOTICE: countability Program to e served: 01/11. ccordance with Title 1 e: 01/11/202	failed the state's test(s). er) OR a test result of .04 g a petition in the District (ipate in the Impaired Dri arrest from appearing o)) days of the date listed b the person named in 1/2021 Sig 2 O.S. Section 426, "	In addition, your co or more while opera- Court of the County iver Accountability in your driving rec I below. Mail the re- ivered a copy of in Section 1 about gnature of officer	mmercial driving privilege ating a commercial motor in which you were arreste y Program (IDAP) admini- ord. Participation in ID/ equest for IDAP to the D f the above containing ye.	in this state will be vehicle. You may a do. Your petition m istered by the Dep AP may reduce the partment of Pub g the Notice of F	disqualificappeal an ust be file partment e amount olic Safety Revocati	ad if you refused y Departmental a d within thirty (30 of Public Safety of fees you will at P.O. Box 114 on and the No	or failed the ction again of the ction again of the ction again (DPS). Concept of the ction of t	e state's testi st your drive e date listed mpletion of od to pay to oma City, Oi epartment	r license below. IDAP ma the State K 73136. Impaired	You must
s or more, if you refused or erating a CMV or CDL holde result of this arrest by filing may be eligible to partic location as a result of this usest IDAP within thirty (30 RVING OF NOTICE: countability Program to e served: 01/11.	failed the state's test(s). er) OR a test result of .04 g a petition in the District (ipate in the Impaired Dri arrest from appearing o)) days of the date listed b the person named in 1/2021 Sig 2 O.S. Section 426, "	In addition, your co or more while opera- Court of the County iver Accountability in your driving rec I below. Mail the re- ivered a copy of in Section 1 about gnature of officer	mmercial driving privilege alting a commercial motor in which you were arrested Program (IDAP) adminiord. Participation in IDA equest for IDAP to the Difference of the above containing we.	in this state will be vehicle. You may add. Your petition m istered by the DepAP may reduce the partment of Public of the Notice of Full of the laws of C	disqualificappeal an ust be file partment e amount boild Safety Revocati	ad if you refused by Departmental a dividing the thing of Public Safety of fees you will at P.O. Box 114 on and the No a that the fore	or failed the ction again of the ction again of the ction again (DPS). Concept of the ction of t	e state's testi st your drive e date listed mpletion of od to pay to oma City, Oi epartment	r license below. IDAP ma the State K 73136. Impaired	You must

Certifica	te of Analysis - Wet Bath		
8/11/200	0.020		
Date of Analysis	Labelled tarke value (g/210L)		
20070	2020	The state of the s	
Lot Number	Acres of Arresolt (7210)	ABORATORIES.	INC.
christophes	Che sangkingan-s	BEETO MARRISBURG, PA 17111-4511	
BOT Technician Name and S		BRT Form 5 D	

In accordance with BRT – 2.2.0, Maintenance, the above referenced simulator solution is sultable for use as an external reference in maintenance of the intoxilyzer 8000.

SN 80-004923

09:49

09:50

09:51

09:51

09:52

19:53

09:53

09:54

09:54

CERTIFICATE OF ANALYSIS

6/1/2020

-5470

08/11/2020		09:42
Test	g/210L	Time
Air Blank	0,000	09:42
Cal Check	0.020	09:43
Air Blank	0.000	09:43
Cal Check	0.020	09:44
Air Blank	0.000	09:45
Cal Check	0.020	09:45
Air Blank	0.000	09:46
Cal Check	0.020	09:47
Air Blank	0.000	09:47
Cal Check	0.021	09:48
Air Blank	0.000	09:48
Cal Check	0.020	00.40

0.000

0.020

0.000

0.020

0,000

0.020

0,000

0.019

0.000

0.0200

0.0004

2,3569

ALPHA INSTRUMENT 2 Intoxilyzer - Alcohol Analyzer

Model 8000

Air Blank

Cal Check

Air Blank

Cal Check

Air Blank

Cal Check

Air Blank

Cal Check

Air Blank

Average Std Dev

Cal Check Stats

Rel Std Deu(%)

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number 20070 of Alcohol Reference Solution for Simulator were analyzed by gas chromatography on February 17, 2020, using a Perkin Elmer Gas Chromatograph Autosystem XL S/N: 610N9030209, and found to contain 0.0242% (w/vol) ethyl alcohol. The expiration date for this lot number is February 13, 2022 at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.020 g/210L +/- 3%.

The alcohol and water used in this solution were free of test interfering substances.

Operator's Signature

Ted L. Pauley, President GUTH LABORATORIES, INC.

NIST Traceability:

Testing was conducted using Cerilliant Reference Standard lot number FN08031603 whose values are traceable to NIST.

May 1994 from
ABORATORIES, INC.
EET HARRISBURG, PA 17111- 4511 TELEPHONE: 717-564-54 BRT Form 6.0

In accordance with BRT – 2.2.0, Maintenance, the above referenced simulator solution is suitable for use as an external reference in maintenance of the Intoxilyzer 8000.

CERTIFICATE OF ANALYSIS

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number 20060 of

Alcohol Reference Solution for Simulator were analyzed by
gas chromatography on February 11, 2020, using a Perkin Elmer Gas
Chromatograph Autosystem XL S/N: 610N9030209, and found to contain
0.0483% (w/vol) ethyl alcohol. The expiration date for this lot
number is February 10, 2022 at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.040 g/210L +/- 3%.

The alcohol and water used in this solution were free of test interfering substances.

Operator's Signature

ALPHA UNIT SUB

Model 8000

07/22/2020

Test

Air Blank

Cal Check

Air Blank

Std Deu

Cal Check Stats Average

Rel Std Deu(%)

Intoxilyzer - Alcohol Analyzer

9/210L

0.000

0.040

0.000

0.039

0.000

0.039

0.000

0.039

0.000

0.039

0.000

0.039

0.000

0.040

0.000

0.040

0.000

0.040

0.000

0.040

0.000

0.0395

0.0005

1,3342

SN 80-003400

14:57

Time

14:57

14:58

14:59

14:59

15:00

15:01

15:01

15:02

15:02

15:03

15:04

15:04

15:05

15:06

15:06

15:07

15:07

15:08

15:09

15:09

15:10

Ted L. Pauley, President GUTH LABORATORIES, INC.

NIST Traceability:

Testing was conducted using Cerilliant Reference Standard lot number FN12181501 whose values are traceable to NIST.



ABORATORIES, INC.

REF BRY Form 6.0 RISE URG, PA 17111- 4511 O TELEPHONE: 717-564-5470

In accordance with BRT – 2.2.0, Maintenance, the above referenced simulator solution is suitable for use as an external reference in maintenance of the intoxilyzer 8000.

CERTIFICATE OF ANALYSIS

ALPHA INSTRUMENT Intoxilyzer - Alcohol Analyzer

Model 8000 SN 80-002591 06/16/2020 16:18

SN 80-002591 Certified Alcohol Reference Solution for Simulator

Test g/210L Time Air Blank 0.000 Cal Check 0.099 16:19 Air Blank 0.000 16:20 Cal Check 0.098 16:20 Air Blank 0.000 16:21 Cal Check 0.097 16:22 Air Blank 0.000 16:22 Cal Check 0.098 16:23 Air Blank 0.000 16:24 Cal Check 0.098 16:24 Air Blank 0.000 16:25 Cal Check 0.098 16:26 Air Blank 0.000 16:26 Cal Check 0.098 16:27 air Blank 0.000 16:27 Cal Check 0.097 16:28 air Blank 0.000 16:29 :al Check 0.098 15:29 Hir Blank 0.000 16:30 :al Check 0.098 15:31 lir Blank 0.000 16:31 'al Check Stats Average 0.0979 Std Deu 0.0005

Random Samples of Lot Number 20190 of Alcohol Reference Solution for Simulator were analyzed by gas chromatography on April 8, 2020, using a Perkin Elmer Gas Chromatograph Autosystem XL S/N: 610N9030209, and found to contain 0.1206% (w/vol) ethyl alcohol. The expiration date for this lot number is April 6, 2022 at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.100 g/210L +/- 3%.

The alcohol and water used in this solution were free of test interfering substances.

Operator's Signature


0,5798

Rel Std Deu(2)

Ted L. Pauley, President GUTH LABORATORIES, INC.

NIST Traceability:

Testing was conducted using Cerilliant Reference Standard lot number FN02271802 whose values are traceable to NIST.



BORATORIES, INC.

MORTH STAN STREET O HARRISBURG, PA 17111-4511 O TELEPHONE: 717-584-5470

BOT Technician Name and Signature

SN 80-003400

15:25

Time

15:26

15:26

15:27

15:28

15:28

15:29

15:30

15:31

15:33

15:34

15:35

15:35

15:36

15:37

15:37

15:38

15:38

In accordance with BRT – 2.2.0, Maintenance, the above referenced simulator solution is suitable for use as an external reference in maintenance of the Intoxilyzer 8000.

CERTIFICATE OF ANALYSIS

BRT Form 6.0

Certified Alcohol Reference Solution for Simulator

Random Samples of Lot Number 20160 of Alcohol Reference Solution for Simulator were analyzed by gas chromatography on March 20, 2020, using a Perkin Elmer Gas Chromatograph Autosystem XL S/N: 610N9030209, and found to contain 0.2427% (w/vol) ethyl alcohol/ The expiration date for this lot number is March 18, 2022 at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.200 g/210L +/- 3%.

The alcohol and water used in this solution were free of test interfering substances.

Operator s Signature

LPHR UNIT SUB ntoxilyzer - Ricohol Analyzer

g/210L

0.000

0.196

0.000

0.196

0.000

0.197

0.000

0.196

0.000

0.198

0.000

0.198

0.000

0.197

0.000

0.198

0.000

0,198

0.000

0.197

0.000

0.1971

0.0008

0.4442

0008 lebc

7/07/2020

est

ir Blank

al Check

ir Blank al Check

iir Blank

al Check

ir Blank

Average

Std Dev Rel Std Dev(%)

al Check Stats

Ted L. Pauley, President GUTH LABORATORIES, INC.

NIST Traceability:

Testing was conducted using Cerilliant Reference Standard lot number FN08101505 whose values are traceable to NIST.