

# Service Overview

Board of Tests for Alcohol and Drug Influence  
Enhancing public safety by ensuring the accuracy and scientific reliability  
of blood and breath testing



3600 N. Martin Luther King Bldg #9  
Oklahoma City, OK 73111  
405-425-2460

**BENCH CHECK DATE:** 06-27-2018

**SERIAL:** 80-006158

## **DOCUMENTATION WITHIN SERVICE PACKET:**

- BOT Certificate of Calibration and Operation
- Bench Check
- Bench Check Technician's Report
- BOT Dry Gas Certificate of Analysis
- Mock Subject Test
- BOT Certificates of Analysis on Certified Solutions (4)



Date:

Re: Request for Log of Test on Intoxilyzer 8000

Name:

Dear Sir:

The Log of Test information from a breath test conducted on a Intoxilyzer 8000 is printed in Section 2 of the Affidavit and is no longer retained as a separate form as with the Intoxilyzer 5000. The 8000 uses a nitrogen/ethanol dry gas for the external control test. The dry gas cylinder has the capacity to perform approximately 325 tests and does not require maintenance until its expiration date or can no longer provide the required pressure to perform a control test. The cylinder has an expiration date of two years from date filled at the manufacturer and is programmed in the 8000 upon installation, both dates are printed in Section 2 of the Affidavit. The Intoxilyzer is programmed to disable itself when the date of expiration is reached or the pressure monitor indicates 25 lbs psi.

Due to the reliability and stability of dry gas, maintenance on the 8000 is not required every 30 days or 25 tests, therefore maintenance is no longer performed by officers in the field. The Board of Tests for Alcohol and Drug Influence certifies each Intoxilyzer 8000 for field use by performing a bench check. The bench check is designed to check the operation and procedures programmed in the 8000 to ensure it is functioning properly for use in Oklahoma. A bench check is performed every time a new dry gas cylinder is installed or the instrument has returned from the manufacturer for repair. Once the instrument passes the bench check, all that is required to set it up for field use is to plug it in and turn it on and does not require a permit to set up. The Board of Tests has the ability to monitor each instrument once it is set up in the field.

Each Intoxilyzer has a database of valid permit numbers that it checks prior to allowing a breath test to be performed. The database is updated on a regular basis, if a permit number is invalid that officer will not be able to conduct a breath test on the 8000. If the 8000 prints an affidavit the breath test operator listed in Section 2 had a valid permit at the time of the test and the breath test is valid.

If you have any further questions please feel free to call me.

Sincerely,



J. Robert Blakeburn (OBA11059)  
State Director of Tests for Alcohol  
and Drug Influence

**STATE OF OKLAHOMA - DEPARTMENT OF PUBLIC SAFETY  
CMI INTOXILYZER BENCH CHECK PROCEDURE REPORT**

BENCH CHECK DATE <b>06/27/2018</b>	TIME PROCEDURE BEGAN <b>09:24</b>	INSTRUMENT LOCATION <b>80-006158</b>
INSTRUMENT TYPE <b>Intoxilyzer</b>	INSTRUMENT MODEL <b>I-8000</b>	INSTRUMENT SERIAL NUMBER <b>80-006158</b>

**TEST RESULTS**

**Diagnostics**

PASS

**Mouth Alcohol Test**

PASS

**RFI Test**

PASS

**Abort Test**

PASS

**Improper Sample Test**

PASS

**Interferent Detect Test**

PASS

**No Sample Given Test**

PASS

**Insufficient Sample Test**

PASS

**Air Blank Contamination Test**

PASS

**Range Exceeded Test**

PASS

**Duplicate Breath Sampling Results**

Value	Test 1	Test 2	Control Test
.02	0.017	0.016	0.017
.04	0.036	0.036	0.036
.10	0.099	0.095	0.097
.20	0.197	0.196	0.198

PASS

**CERTIFYING TECHNICIAN**

I swear under penalty of perjury that in regards to the above listed instrument, I have complied with the Intoxilyzer Bench Checking Procedure approved by the State of Oklahoma.

SIGNATURE 	DATE <b>06/27/2018</b>
NAME <b>SMITH, JOSHUA</b>	PERMIT # <b>0000016837</b>



3600 N. Martin Luther King Bldg #9  
 Oklahoma City, OK 73111  
 405-425-2460

# BENCH CHECK TECHNICIAN'S REPORT

Date: 06 / 27 / 18 Start Time: 0915 End Time: 1300

## INSTRUMENT

Intoxilyzer Model 8000 Serial # 80-006158

## GAS CANISTER

LOT # 10819080A5 # 045 EXP Date 6-5-2020


## REFERENCE

Simulator Model			
Guth 2100	Guth 2100	Guth 2100	Guth 2100
Serial #			
DR3591	DR3753	DR3594	DR3754
Concentration			
.02	.04	.10	.20
LOT #			
16400	16320	17130	17090
Manufactured Date			
12-12-2016	10-21-2016	04-03-2017	02-24-2017
Expiration Date			
12-12-2018	10-21-2018	04-03-2019	02-24-2019
Solution Commission Date			
<u>06/25/18</u>	<u>06/25/18</u>	<u>06/25/18</u>	<u>06/25/18</u>


## REASON FOR BENCH CHECK

- POST REPAIR 
  CYLINDER REPLACEMENT  
 TROUBLESHOOTING 
  ROUTINE MAINTENANCE

## COMMENTS


 16037  
 Technician Signature / Permit #

Josh Smith  
 Printed Name

Certificate of Analysis – Dry Gas	
06/27/2018	.080
Date of Analysis	Labeled target value (g/210L)
#045	.0789
Cylinder #	Average test result
 BOT Technician Name and Signature	



7 Eastgate Dr. • P.O. Box 790 • Jacksonville, IL 62651-0790  
 217-245-2183 • Fax: 217-243-7634 • www.ilmoproducts.com

ALPHA INSTRUMENT 2  
 Intoxilyzer - Alcohol Analyzer  
 Model 8000 SN 80-004923  
 06/27/2018 09:24

Test	g/210L	Time
Air Blank	0.000	09:25
Cal Check	0.079	09:25
Air Blank	0.000	09:26
Cal Check	0.079	09:26
Air Blank	0.000	09:27
Cal Check	0.079	09:27
Air Blank	0.000	09:27
Cal Check	0.078	09:28
Air Blank	0.000	09:28
Cal Check	0.079	09:29
Air Blank	0.000	09:29
Cal Check	0.079	09:29
Air Blank	0.000	09:30
Cal Check	0.079	09:30
Air Blank	0.000	09:31
Cal Check	0.079	09:31
Air Blank	0.000	09:32
Cal Check	0.079	09:32
Air Blank	0.000	09:32
Cal Check	0.079	09:33
Air Blank	0.000	09:33
Cal Check Stats		
Average	0.0789	
Std Dev	0.0003	
Rel Std Dev(%)	0.4007	

## Certificate of Analysis

**Certificate ID:** 11093  
**Part #:** BAC105L080T  
**Cylinder Size:** 105L  
**Lot Number:** 10818080A5 ✓  
**Expiration:** 6/5/2020 ✓

REC'D  
 05/21/18  


0.080 BAC (For the calibration of instruments used to determine breath alcohol concentration)

**Contents:** 105 Liters @ 1000 psig 70°F (21°C)

Component:	Reported Concentration:	Analytical Accuracy (U, k=2):	Analytical Method:
Ethanol	208 ppm	+/-0.002 BAC(G/210L) [5.2 ppm]	NDIR
Nitrogen	Balance		

**Distributed by:**  
 CMI Inc.  
 316 East Ninth Street  
 Owensboro, KY 42301  
 Phone 866-835-0690  
[www.alcoholtest.com](http://www.alcoholtest.com)

  
 16837  
 Operator's Signature

\*NIST Traceable Reference Material  
 Cylinder No. CC274523 / Job No. 09160306  
 Certified 362.2 µmol/mol Ethanol in Nitrogen

Store in dry area, away from sources of heat, ignition and direct sunlight. Do not allow storage area to exceed 52 °C (125 °F).

  
 Specialty Gas Lab Tech

05-09-18  
 Date



The calibration results within this certificate were obtained using equipment and standards capable of producing analytical results traceable to NIST, and apply only to the items contained on this certificate. ILMO Products Company makes no warranty or representation as to the suitability of the use of any information provided for any particular purpose. The information use is at the sole discretion and risk of the user. Liability shall be limited to established replacement cost of this material or service.

ISO/IEC 17025:2005 Accredited Laboratory

# OFFICER'S AFFIDAVIT AND NOTICE OF REVOCATION/DISQUALIFICATION

Section 1

ARREST DATE <b>06/27/2018</b>		ARREST TIME <b>1300</b>		COUNTY # <b>55</b>	CITY # <b>55</b>	CITATION # <b>MOCK</b>		
ARREST LOCATION <b>MOCK</b>					CITY <b>MOCK</b>		COUNTY <b>OKLAHOMA</b>	
SUBJECT NAME <b>MOCK, SUBJECT TEST</b>				DATE OF BIRTH <b>08/09/1961</b>	SEX <b>M</b>	RACE <b>W</b>	HEIGHT <b>510</b>	WEIGHT <b>165</b>
ADDRESS <b>3600 MARTIN LUTHER KING A</b>			CITY <b>OKLAHOMA CITY</b>		STATE <b>OK</b>	ZIP CODE <b>73133</b>		
DRIVER LICENSE # <b>T083454871</b>			EXPIRATION DATE <b>06/30/2019</b>	STATE <b>OK</b>	CLASS <b>A</b>	RESTRICTIONS	ENDORSEMENTS <b>M</b>	
VEHICLE MAKE <b>MOCK</b>		MODEL <b>MOCK</b>	TAG # <b>MOCK</b>		STATE <b>OK</b>	CMV <b>N</b>	PLACARD <b>N</b>	

On the above date, time, and location, the above named person was arrested, and I had reasonable grounds to believe the person was driving or in actual physical control of a motor vehicle upon a public road, highway, street, turnpike, public parking lot, or other public place, or upon a private road, street, alley or lane which provides access to one or more single or multi-family dwelling within this state while under the influence of alcohol and/or other intoxicating substances as prohibited by law.

(Describe driving behavior or circumstances):

**MOCK SUBJECT TEST. ROUTINE MAINTENANCE. NEW GAS CANISTER INSTALL.**

Describe person's condition (odor, actions, etc.):

**NONE**

**THE PERSON WAS INFORMED OF THE IMPLIED CONSENT TEST REQUEST**

**BREATH-ALCOHOL ANALYSIS RECORD, REPORT OF THE PERSON NAMED IN SECTION 1 ABOVE, and LOG OF TEST AND MAINTENANCE RECORD.**

Section 2

EQUIPMENT <b>I-8000</b>		SERIAL NUMBER <b>80-006158</b>	SPECIALIST <b>BOARD OF TESTS</b>																																					
STANDARD <b>Dry</b>		TARGET VALUE <b>0.080</b>	PERMIT NUMBER <b>16837</b>																																					
MANUFACTURER <b>ILMO</b>		LOT # <b>10818080A5</b>	DATE CYLINDER INSTALLED <b>06/27/2018</b>	DATE CYLINDER EXPIRES <b>06/05/2020</b>																																				
OBSERVATION START <b>1315</b>	TEST DATE <b>06/27/2018</b>	MOUTHPIECE <b>G</b>	<p>A 15-minute (or greater) deprivation/observation period was observed prior to and continuing to the time of test administration.</p> <p>I administered said Breath-Alcohol Test in compliance with the applicable operating procedure of the Board of Tests.</p> <p>_____ SIGNATURE OF OPERATOR</p> <p>NAME <b>SMITH, JOSHUA</b></p> <p>BADGE # <b>0000000435</b></p> <p>PERMIT # <b>0000016837</b></p> <p>AGENCY <b>BOARD OF TESTS</b></p>																																					
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Test</th> <th>g/210L</th> <th>Time</th> </tr> </thead> <tbody> <tr><td>Air Blank</td><td>0.00</td><td>13:37</td></tr> <tr><td>Subject Test</td><td>0.00</td><td>13:38</td></tr> <tr><td>Breath Volume</td><td>2.054 LITERS</td><td></td></tr> <tr><td>Air Blank</td><td>0.00</td><td>13:38</td></tr> <tr><td>Wait</td><td></td><td>13:40</td></tr> <tr><td>Air Blank</td><td>0.00</td><td>13:40</td></tr> <tr><td>Subject Test</td><td>0.00</td><td>13:41</td></tr> <tr><td>Breath Volume</td><td>1.480 LITERS</td><td></td></tr> <tr><td>Air Blank</td><td>0.00</td><td>13:41</td></tr> <tr><td>Cal Check</td><td>0.07</td><td>13:42</td></tr> <tr><td>Air Blank</td><td>0.00</td><td>13:42</td></tr> </tbody> </table>					Test	g/210L	Time	Air Blank	0.00	13:37	Subject Test	0.00	13:38	Breath Volume	2.054 LITERS		Air Blank	0.00	13:38	Wait		13:40	Air Blank	0.00	13:40	Subject Test	0.00	13:41	Breath Volume	1.480 LITERS		Air Blank	0.00	13:41	Cal Check	0.07	13:42	Air Blank	0.00	13:42
Test	g/210L	Time																																						
Air Blank	0.00	13:37																																						
Subject Test	0.00	13:38																																						
Breath Volume	2.054 LITERS																																							
Air Blank	0.00	13:38																																						
Wait		13:40																																						
Air Blank	0.00	13:40																																						
Subject Test	0.00	13:41																																						
Breath Volume	1.480 LITERS																																							
Air Blank	0.00	13:41																																						
Cal Check	0.07	13:42																																						
Air Blank	0.00	13:42																																						
			<div style="border: 1px solid black; padding: 5px; width: fit-content; margin: auto;"> <p>Test Result BrAC g/210L <b>0.00</b></p> </div>																																					

**EFFECTIVE THIRTY (30) DAYS FROM DATE SERVED. Notice of Revocation** is given that your driver's license is revoked or denied for a

Section 3

period of one hundred eighty (180) days or more, if you refused or failed the state's test(s). In addition, your commercial driving privilege in this state will be disqualified if you refused or failed the state's test(s) (operating a CMV or CDL holder) OR a test result of .04 or more while operating a commercial motor vehicle. To appeal the driver's license revocation/disqualification, the Department of Public Safety must receive your written request for an Administrative Hearing **within fifteen (15) days from the date you received notice of revocation or disqualification**. Submit your **written** request in person at 3600 N. MLK Ave. or by mail to Legal Division, Department of Public Safety, P.O. Box 11415, OKC, OK, 73136

**SERVING OF NOTICE:** I personally hand-delivered a copy of the above containing the Notice of Revocation to the person named in Section 1 above.

Date served: **06/27/2018** Signature of officer: \_\_\_\_\_ Badge #: \_\_\_\_\_

In accordance with Title 12 O.S. Section 426, "I state under **penalty of perjury** under the laws of Oklahoma that the foregoing is true and correct."

Section 4

Date: **06/27/2018** Place (location when signed): \_\_\_\_\_ Signature of arresting officer: \_\_\_\_\_

NAME <b>SMITH, JOSHUA</b>		AGENCY <b>BOARD OF TESTS</b>	
BADGE <b>0000000435</b>	AGENCY ADDRESS <b>INTER-AGENCY</b>	ZIP CODE <b>00000</b>	PHONE <b>"4054252460"</b>

**OTHER WITNESSES:**

Section 5

1	NAME	TITLE	ADDRESS	PHONE
2	NAME	TITLE	ADDRESS	PHONE

No Temporary License Issued:  
Test Below Legal Limit

# OFFICER'S AFFIDAVIT AND NOTICE OF REVOCATION/DISQUALIFICATION

Section 1

ARREST DATE <b>06/27/2018</b>		ARREST TIME <b>1300</b>		COUNTY # <b>55</b>	CITY # <b>55</b>	CITATION # <b>MOCK</b>		
ARREST LOCATION <b>MOCK</b>					CITY <b>MOCK</b>	COUNTY <b>OKLAHOMA</b>		
SUBJECT NAME <b>MOCK, SUBJECT TEST</b>				DATE OF BIRTH <b>08/09/1961</b>	SEX <b>M</b>	RACE <b>W</b>	HEIGHT <b>510</b>	WEIGHT <b>165</b>
ADDRESS <b>3600 MARTIN LUTHER KING A</b>				CITY <b>OKLAHOMA CITY</b>		STATE <b>OK</b>	ZIP CODE <b>73133</b>	
DRIVER LICENSE # <b>T083454871</b>			EXPIRATION DATE <b>06/30/2019</b>	STATE <b>OK</b>	CLASS <b>A</b>	RESTRICTIONS	ENDORSEMENTS <b>M</b>	
VEHICLE MAKE <b>MOCK</b>		MODEL <b>MOCK</b>		TAG # <b>MOCK</b>		STATE <b>OK</b>	CMV <b>N</b>	PLACARD <b>N</b>

On the above date, time, and location, the above named person was arrested, and I had reasonable grounds to believe the person was driving or in actual physical control of a motor vehicle upon a public road, highway, street, turnpike, public parking lot, or other public place, or upon a private road, street, alley or lane which provides access to one or more single or multi-family dwelling within this state while under the influence of alcohol and/or other intoxicating substances as prohibited by law.

(Describe driving behavior or circumstances):

**MOCK SUBJECT TEST. ROUTINE MAINTENANCE. NEW GAS CANISTER INSTALL.**

Describe person's condition (odor, actions, etc.):

**NONE**

**THE PERSON WAS INFORMED OF THE IMPLIED CONSENT TEST REQUEST**

**BREATH-ALCOHOL ANALYSIS RECORD, REPORT OF THE PERSON NAMED IN SECTION 1 ABOVE, and LOG OF TEST AND MAINTENANCE RECORD.**

Section 2

EQUIPMENT <b>I-8000</b>		SERIAL NUMBER <b>80-006158</b>	SPECIALIST <b>BOARD OF TESTS</b>																																								
STANDARD <b>Dry</b>		TARGET VALUE <b>0.080</b>	PERMIT NUMBER <b>16837</b>																																								
MANUFACTURER <b>ILMO</b>		LOT # <b>10818080A5</b>	DATE CYLINDER INSTALLED <b>06/27/2018</b>	DATE CYLINDER EXPIRES <b>06/05/2020</b>																																							
OBSERVATION START <b>1315</b>	TEST DATE <b>06/27/2018</b>	MOUTHPIECE <b>G</b>	<p style="text-align: center;">A 15-minute (or greater) deprivation/observation period was observed prior to and continuing to the time of test administration.</p> <p style="text-align: center;">I administered said Breath-Alcohol Test in compliance with the applicable operating procedure of the Board of Tests.</p> <p style="text-align: center;">SIGNATURE OF OPERATOR _____</p>																																								
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Test</th> <th>g/210L</th> <th>Time</th> </tr> </thead> <tbody> <tr><td>-----</td><td>-----</td><td>-----</td></tr> <tr><td>Air Blank</td><td>0.00</td><td>13:37</td></tr> <tr><td>Subject Test</td><td>0.00</td><td>13:38</td></tr> <tr><td>  Breath Volume</td><td>2.054 LITERS</td><td></td></tr> <tr><td>Air Blank</td><td>0.00</td><td>13:38</td></tr> <tr><td>Wait</td><td></td><td>13:40</td></tr> <tr><td>Air Blank</td><td>0.00</td><td>13:40</td></tr> <tr><td>Subject Test</td><td>0.00</td><td>13:41</td></tr> <tr><td>  Breath Volume</td><td>1.480 LITERS</td><td></td></tr> <tr><td>Air Blank</td><td>0.00</td><td>13:41</td></tr> <tr><td>Cal Check</td><td>0.07</td><td>13:42</td></tr> <tr><td>Air Blank</td><td>0.00</td><td>13:42</td></tr> </tbody> </table>					Test	g/210L	Time	-----	-----	-----	Air Blank	0.00	13:37	Subject Test	0.00	13:38	Breath Volume	2.054 LITERS		Air Blank	0.00	13:38	Wait		13:40	Air Blank	0.00	13:40	Subject Test	0.00	13:41	Breath Volume	1.480 LITERS		Air Blank	0.00	13:41	Cal Check	0.07	13:42	Air Blank	0.00	13:42
Test	g/210L	Time																																									
-----	-----	-----																																									
Air Blank	0.00	13:37																																									
Subject Test	0.00	13:38																																									
Breath Volume	2.054 LITERS																																										
Air Blank	0.00	13:38																																									
Wait		13:40																																									
Air Blank	0.00	13:40																																									
Subject Test	0.00	13:41																																									
Breath Volume	1.480 LITERS																																										
Air Blank	0.00	13:41																																									
Cal Check	0.07	13:42																																									
Air Blank	0.00	13:42																																									
RESULT TABLE			<div style="border: 1px solid black; padding: 5px; width: fit-content; margin: auto;"> <p>Test Result BrAC g/210L <b>0.00</b></p> </div>																																								
<p>NAME <b>SMITH, JOSHUA</b></p> <p>BADGE # <b>0000000435</b></p> <p>PERMIT # <b>0000016837</b></p> <p>AGENCY <b>BOARD OF TESTS</b></p>																																											

**EFFECTIVE THIRTY (30) DAYS FROM DATE SERVED. Notice of Revocation** is given that your driver's license is revoked or denied for a period of one hundred eighty (180) days or more, if you refused or failed the state's test(s). In addition, your commercial driving privilege in this state will be disqualified if you refused or failed the state's test(s) (operating a CMV or CDL holder) OR a test result of .04 or more while operating a commercial motor vehicle. To appeal the driver's license revocation/disqualification, the Department of Public Safety must receive your written request for an Administrative Hearing **within fifteen (15) days from the date you received notice of revocation or disqualification**. Submit your **written** request in person at 3600 N. MLK Ave. or by mail to Legal Division, Department of Public Safety, P.O. Box 11415, OKC, OK, 73136

Section 3

**SERVING OF NOTICE:** I personally hand-delivered a copy of the above containing the Notice of Revocation to the person named in Section 1 above.

Date served: **06/27/2018** Signature of officer: \_\_\_\_\_ Badge #: \_\_\_\_\_

In accordance with Title 12 O.S. Section 426, "I state under **penalty of perjury** under the laws of Oklahoma that the foregoing is true and correct."

Section 4

Date: **06/27/2018** Place (location when signed): \_\_\_\_\_ Signature of arresting officer: \_\_\_\_\_

NAME <b>SMITH, JOSHUA</b>		AGENCY <b>BOARD OF TESTS</b>	
BADGE <b>0000000435</b>	AGENCY ADDRESS <b>INTER-AGENCY</b>	ZIP CODE <b>00000</b>	PHONE <b>"4054252460"</b>

No Temporary License Issued:  
Test Below Legal Limit

ARRESTEE'S COPY  
BOT Form AFF02 07/2008



Certificate of Analysis - Wet Bath	
05-05-17	.020
Date of Analysis	Labelled target value (g/210L)
16400	.0195
Lot Number	Average test result (g/210L)
Jbst Smith	
BOT Technician Name and Signature	



**GUTH LABORATORIES, INC.**  
 G, PA 17111-4511 • TELEPHONE: 717-564-5470

BRT Form 6.0

In accordance with BRT - 2.1.0, Maintenance, the above referenced simulator solution is suitable for use as an external reference in maintenance of the Intoxilyzer 8000.

**CERTIFICATE OF ANALYSIS**

INTOXILYZER 8000  
 Instrument Initialization  
 8133.12  
 14:48 05/05/2017

Certified Alcohol Reference Solution for Simulator

Rec'd  
 4/01/2017  
 #16837

Random Samples of Lot Number 16400 of Alcohol Reference Solution for Simulator were analyzed by gas chromatography on December 13, 2016, using a Perkin Elmer Gas Chromatograph Autosystem XL S/N: 610N9030209, and found to contain 0.0241% (w/vol) ethyl alcohol. The expiration date for this lot number is December 12, 2018 at 11:59 PM.

ALPHA INSTRUMENT 2  
 Intoxilyzer - Alcohol Analyzer  
 Model 8000 SN 80-004923  
 05/05/2017 14:56

Test	g/210L	Time
Air Blank	0.000	14:57
Cal Check	0.020	14:58
Air Blank	0.000	14:58
Cal Check	0.020	14:59
Air Blank	0.000	14:59
Cal Check	0.019	15:00
Air Blank	0.000	15:01
Cal Check	0.020	15:01
Air Blank	0.000	15:02
Cal Check	0.020	15:03
Air Blank	0.000	15:03
Cal Check	0.020	15:04
Air Blank	0.000	15:04
Cal Check	0.019	15:05
Air Blank	0.000	15:06
Cal Check	0.019	15:06
Air Blank	0.000	15:07
Cal Check	0.019	15:08
Air Blank	0.000	15:08
Cal Check	0.019	15:09
Air Blank	0.000	15:09

Cal Check Stats  
 Average 0.0195  
 Std Dev 0.0005  
 Rel Std Dev(%) 2.7026


#16837

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.020 g/210L +/- 3%.

The alcohol and water used in this solution were free of test interfering substances.

*Ted L. Pauley*  
 Ted L. Pauley, President  
 GUTH LABORATORIES, INC.

**NIST Traceability:**  
 Testing was conducted using Cerilliant Reference Standard lot number FN11241503 whose values are traceable to NIST.  
 All balances are calibrated annually by an outside agency using NIST traceable weights. Calibration verification is done prior to each use utilizing NIST traceable weights.

Certificate of Analysis – Wet Bath	
3-8-2017	.040
Date of Analysis	Labelled target value (g/210L)
16320	.0409
Lot Number	Average test result (g/210L)
Josh Smith 	
BOT Technician Name and Signature	




**GUTH LABORATORIES, INC.**  
 HUNTSBURG, PA 17111-4511 • TELEPHONE: 717-564-5470

BRT Form 5.0

In accordance with BRT – 2.1.0, *Maintenance*, the above referenced simulator solution is suitable for use as an external reference in maintenance of the Intoxilyzer 8000.

**CERTIFICATE OF ANALYSIS**

Certified Alcohol Reference Solution for Simulator

REC'D  
 03/01/17  
  
 #16837


Random Samples of Lot Number 16320 ✓ of Alcohol Reference Solution for Simulator were analyzed by gas chromatography on **October 25, 2016**, using a Perkin Elmer Gas Chromatograph Autosystem XL S/N: 610N9030209, and found to contain **0.0495%** (w/vol) ethyl alcohol. The expiration date for this lot number is **October 21, 2018** at 11:59 PM.

ALPHA INSTRUMENT 2  
 Intoxilyzer - Alcohol Analyzer  
 Model 8000  
 03/08/2017

Test	g/210L	Time
Air Blank	0.000	11:16
Cal Check	0.041	11:17
Air Blank	0.000	11:17
Cal Check	0.041	11:18
Air Blank	0.000	11:19
Cal Check	0.040	11:19
Air Blank	0.000	11:20
Cal Check	0.041	11:21
Air Blank	0.000	11:21
Cal Check	0.041	11:22
Air Blank	0.000	11:22
Cal Check	0.041	11:23
Air Blank	0.000	11:24
Cal Check	0.041	11:24
Air Blank	0.000	11:25
Cal Check	0.040	11:26
Air Blank	0.000	11:26
Cal Check	0.042	11:27
Air Blank	0.000	11:27
Cal Check	0.041	11:28
Air Blank	0.000	11:29
Cal Check Stats		
Average	0.0409	
Std Dev	0.0005	
Rel Std Dev(%)	1.3878	

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of **0.040 g/210L +/- 3%**. ✓

The alcohol and water used in this solution were free of test interfering substances.

  
 Ted L. Pauley, President  
 GUTH LABORATORIES, INC.

  
 #16837

*NIST Traceability:*  
 Testing was conducted using Cerilliant Reference Standard lot number **FN1218501** whose values are traceable to NIST.  
 All balances are calibrated annually by an outside agency using NIST traceable weights. Calibration verification is done prior to each use utilizing NIST traceable weights.

Certificate of Analysis – Wet Bath	
06/15/2017	.10
Date of Analysis	Labelled target value (g/210L)
17130	.1015
Lot Number	Average test result (g/210L)
J. Smith	
BOT Technician Name and Signature	



**GUTH LABORATORIES, INC.**  
 BURG, PA 17111-4511 • TELEPHONE: 717-564-5470

BRT Form 6.0

In accordance with BRT – 2.1.0, Maintenance, the above referenced simulator solution is suitable for use as an external reference in maintenance of the Intoxilyzer 8000.

**CERTIFICATE OF ANALYSIS**

REC'D  
 06/09/2017  
 J. Smith

ALPHA INSTRUMENT 2  
 Intoxilyzer - Alcohol Analyzer  
 Model 8000  
 06/15/2017

SN 80-004923  
 16:25

**Certified Alcohol Reference Solution for Simulator**

Test	g/210L	Time
Air Blank	0.000	16:26
Cal Check	0.102	16:26
Air Blank	0.000	16:27
Cal Check	0.102	16:28
Air Blank	0.000	16:28
Cal Check	0.101	16:29
Air Blank	0.000	16:29
Cal Check	0.102	16:30
Air Blank	0.000	16:31
Cal Check	0.101	16:31
Air Blank	0.000	16:32
Cal Check	0.101	16:33
Air Blank	0.000	16:33
Cal Check	0.102	16:34
Air Blank	0.000	16:34
Cal Check	0.101	16:35
Air Blank	0.000	16:36
Cal Check	0.102	16:36
Air Blank	0.000	16:37
Cal Check	0.101	16:38
Air Blank	0.000	16:38
Cal Check Stats		
Average	0.1015	
Std Dev	0.0005	
Rel Std Dev(%)	0.5192	

Random Samples of Lot Number **17130** of Alcohol Reference Solution for Simulator were analyzed by gas chromatography on **April 6, 2017**, using a Perkin Elmer Gas Chromatograph Autosystem XL S/N: 610N9030209, and found to contain **0.1212%** (w/vol) ethyl alcohol. The expiration date for this lot number is **April 3, 2019** at 11:59 PM. ✓


When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of **0.100 g/210L +/- 3%**. ✓

The alcohol and water used in this solution were free of test interfering substances.

*Ted L. Pauley*  
 Ted L. Pauley, President  
 GUTH LABORATORIES, INC.

*J. Smith*  
 Operator's Signature

**NIST Traceability:**  
 Testing was conducted using Cerilliant Reference Standard lot number FN08051301 whose values are traceable to NIST.  
 All balances are calibrated annually by an outside agency using NIST traceable weights. Calibration verification is done prior to each use utilizing NIST traceable weights.

Certificate of Analysis - Wet Bath	
06-16-17	.20
Date of Analysis	Labelled target value (g/210L)
17090	.2045
Lot Number	Average test result (g/210L)
 BOT Technician Name and Signature	



**GUTH LABORATORIES, INC.**  
 HARRISBURG, PA 17111-4511 • TELEPHONE: 717-564-5470

BRT Form 6.0

In accordance with BRT - 2.1.0, Maintenance, the above referenced simulator solution is suitable for use as an external reference in maintenance of the Intoxilyzer 8000.

*REC'D  
 06/09/17  
 16837*

**CERTIFICATE OF ANALYSIS**

ALPHA INSTRUMENT 2  
 Intoxilyzer - Alcohol Analyzer  
 Model 8000 SN 80-004923  
 06/16/2017 10:52

Certified Alcohol Reference Solution for Simulator

Test	g/210L	Time
Air Blank	0.000	10:53
Cal Check	0.204	10:53
Air Blank	0.000	10:54
Cal Check	0.205	10:55
Air Blank	0.000	10:55
Cal Check	0.205	10:56
Air Blank	0.000	10:57
Cal Check	0.205	10:57
Air Blank	0.000	10:58
Cal Check	0.205	10:59
Air Blank	0.000	10:59
Cal Check	0.205	11:00
Air Blank	0.000	11:00
Cal Check	0.204	11:01
Air Blank	0.000	11:02
Cal Check	0.204	11:02
Air Blank	0.000	11:03
Cal Check	0.204	11:04
Air Blank	0.000	11:04
Cal Check	0.204	11:05
Air Blank	0.000	11:05
Cal Check Stats		
Average	0.2045	
Std Dev	0.0005	
Rel Std Dev(%)	0.2577	

Random Samples of Lot Number 17090 of Alcohol Reference Solution for Simulator were analyzed by gas chromatography on February 27, 2017, using a Perkin Elmer Gas Chromatograph Autosystem XL S/N: 610N9030209, and found to contain 0.2416% (w/vol) ethyl alcohol. The expiration date for this lot number is February 24, 2019 at 11:59 PM.

When used in a calibrated Simulator, operating at 34°C +/- .2°C, this solution will give a breath alcohol analysis instrument reading of 0.200 g/210L +/- 3%.

The alcohol and water used in this solution were free of test interfering substances.

*Ted L. Pauley*

Ted L. Pauley, President  
 GUTH LABORATORIES, INC.

*[Signature]*  
 Operator's Signature  
 16837

**NIST Traceability:**  
 Testing was conducted using Cerilliant Reference Standard lot number FN08101505 whose values are traceable to NIST.  
 All balances are calibrated annually by an outside agency using NIST traceable weights. Calibration verification is done prior to each use utilizing NIST traceable weights.